


ENGINE NUMBER LOCATION POINTS— NON CURRENT ENGINES

Note: The engine number of some engine types can be stamped in one of two positions.

Positions are given below: —

Engine Type	Position	Engine Type	Position
P3.	J.	4.270	D.H.
P3.144	B.	L4.	H.
4.99 (Early Models)	G.	P6.	E.K.
4.99 (Late Models)	A.	6.288	E.K.
4.107.	A.	6.305	E.K.
P4.	E.J.	6C.305	F.
4.192	E.H.J.	6.306	C.
4.236 (Phase 1)	I.	R6.	K.
4.236 (Early Phase 2)	K.	6.340	K.



ENGINE NUMBER LOCATION POINTS— CURRENT ENGINES

The engine number of some engine types can be stamped in one of two positions depending on application. Positions are given below: —

Engine Type	Position	Engine Type	Position
3.152 Family	I	4.300	F
4.108	A	4.318	F
4.154	B	6.247	C or F
4.165	B or E	6.354 Family	D
4.203 Family	G or J	V8.510	K
4.212	C	V8.540	K
4.236	C or H	V8.640	L
4.248	C		

